TECHNICAL DATA

Fluke SCC128 Automotive Troubleshooting kit (120 Series)

Key features

The SCC128 Automotive troubleshooting kit includes:

- C120 Carrying Case for 120-Series ScopeMeter
- SW90W FlukeView ScopeMeter Software package
- OC4USB Serial Interface Cable for connecting the ScopeMeter to a (notebook) PC
- STL90 Shielded Test Leads (red & gray) with 2 ground leads
- Four Backprobe pins (1 red, 1 gray, 2 black),
- Four 4 mm Tip adapters (1 red, 1 gray, 2 black)
- AC85A Sets of Alligator Clips (Four pieces, 1 red, 1 gray, 2 black)
- TL24 Ground lead with banana plugs (1 piece black)
- C75 Softcase, for holding and storing all smaller items
- Low pass filter adapters (2 pieces)
- BNC(m) to BNC(f) extension cables (2 pieces)
- BB120, Shielded banana to BNC adapter (1 piece)
- … plus ample storage space to hold all standard accessories and manuals, included with the ScopeMeter testtool

(ScopeMeter testtool not included in SCC128)

Product overview: Fluke SCC128 Automotive Troubleshooting kit (120 Series)

Using the ScopeMeter 120 Series in dedicated applications like automotive electronics troubleshooting, often requires special accessories like adapters, connectors and test leads to establish the measurement connection to the circuitry under test. The Fluke SCC128 kit provides a host of accessories that allow you to easily and quickly make measurements on automotive electronic systems, using a 120 Series ScopeMeter.

Ordering information

Fluke SCC128

Automotive Troubleshooting kit (120 Series

The SCC128 Automotive troubleshooting kit includes:

- C120 Carrying Case for 120-Series ScopeMeter
- SW90W FlukeView ScopeMeter Software package
- OC4USB Serial Interface Cable for connecting the ScopeMeter to a (notebook) PC
- STL90 Shielded Test Leads (red and gray) with 2 ground leads
- Four Backprobe pins (1 red, 1 gray, 2 black)
- Four 4 mm Tip adapters (1 red, 1 gray, 2 black)
- AC85A Sets of Alligator Clips (Four pieces, 1 red, 1 gray, 2 black)
- TL24 Ground lead with banana plugs (1 piece black)
- C75 Softcase, for holding and storing all smaller items
- Low pass filter adapters (2 pieces)
- BNC(m) to BNC(f) extension cables (2 pieces)
- BB120, Shielded banana to BNC adapter (1 piece)
- Plus ample storage space to hold all standard accessories and manuals, included with the ScopeMeter test tool

(ScopeMeter test tool not included in SCC128)

Fluke. *Keeping your world up and running.®*

Fluke Europe B.V.
P.O. Box 1186
5602 BD Eindhoven
The Netherlands
www.fluke.com/en
©2023 Fluke Corporation. All rights reserved.
Data subject to alteration without notice.
08/2023

For more information call:
In Middle East/Africa
+31 (0)40 267 5100

Modification of this document is not permitted without written permission from Fluke Corporation.