

# AC/DC voltage monitoring in 1-phase mains

## E1IUM230V01

Monitoring relays - ENYA series Multifunction 1 change over contact Width 17.5 mm Installation design



## **Technical data**

#### 1. Functions

AC/DC voltage monitoring in 1-phase mains with adjustable threshold and hysteresis.

UNDER WIN

Undervoltage monitoring Monitoring the window between Min and Max

#### 2. Time ranges

Adjustment range Start-up suppression time (Start): Tripping delay (Delay):

#### 3. Indicators

Green LED ON/OFF: indication of supply voltage Red LED ON/OFF: indication of failure of the corresponding threshold Yellow LED ON/OFF: indication of output relay

#### 4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on DIN rail TS 35 according to EN 50022 Mounting position: any Shockproof terminal connection according to VBG 4 (PZ1 required), IP rating IP20 Tightening torque: max. 1Nm Terminal capacity: 1 x 0.5 to 2.5mm<sup>2</sup> with/without multicore cable end 1 x 4mm<sup>2</sup> without multicore cable end 2 x 0.5 to 1.5mm<sup>2</sup> with/without multicore cable end 2 x 2.5mm<sup>2</sup> flexible without multicore cable end

### 5. Input circuit

Supply voltage: Terminals: 230V AC 24V AC 24V DC Rated voltage Un: Tolerance:

Rated consumption:

230V AĊ

24V AC

24V DC

Duration of operation:

Overvoltage category:

Rated surge voltage:

Rated frequency:

Reset time:

Wave form:

Hold-up time: Drop-out voltage: (= measuring voltage)

E-F3 E-F2 E-F1(+) see table ordering information or printing on the unit -25% to +20% of Un

10VA (0.6W) 1.3VA (0.8W) 0.6W AC 48 to 63Hz 100% 500ms DC, AC Sinus

determined by undervoltage detection (see measured circuit) III (according to IEC 60664-1) 4kV

#### 6. Output circuit

1 potential free change over contact Rated voltage: Switching capacity: Fusing: 5A fast acting Mechanical life: Electrical life: Switching frequency:

250V AC

4kV

E-E3

E-F1(+) 120% of Un

4kV

1250VA (5A / 250V)

20 x 10<sup>6</sup> operations

2 x 10<sup>5</sup> operations at 1000VA resistive load max. 60/min at 100VA resistive load

max. 6/min at 1000VA resistive load

E-F2 Distance between the devices

(according to IEC 947-5-1)

III. (according to IEC 60664-1)

DC or AC Sinus, 48 to 63Hz

musst be greater than 5mm!

see table ordering information or

see table ordering information or

III (according to IEC 60664-1)

(= supply voltage)

printing on the unit

printing on the unit

≤5% of nominal value

±5% of nominal value

≤2% of nominal value

≤0,05% / °C

Overvoltage category: Rated surge voltage:

### 7. Measuring circuit

Measuring variable: Measuring input: Terminals: 230V AC 24V AC

24V DC Overload capacity: Input resistance: Switching threshold Us:

#### Hysteresis H:

Overvoltage category: Rated surge voltage:

#### 8. Accuracy

Base accuracy: Adjustment accuracy: Repetition accuracy: Voltage influence: Temperature influence:

#### 9. Ambient conditions

Ambient temperature: Storage temperature: Transport temperature: Relative humidity:

Pollution degree:

Vibration resistance:

Shock resistance:

#### 10. Weight Single packing : Package of 10pcs:

-25 to +55°C (according to IEC 68-1) -25 to +70°C -25 to +70°C 15% to 85% (according to IEC 721-3-3 class 3K3) 2, if built in 3 (according to IEC 664-1) 10 to 55 Hz 0.35mm (according to IEC 68-2-6) 15g 11ms (according to IEC 68-2-27)

75g

684g per package

### www.tele-online.com

# E1IUM230V01

# **Functions**

## Undervoltage monitoring (UNDER)

When the supply voltage U is applied, the output relay R switches into on-position, if the measured voltage is beyond the Min-value. When the measured voltage falls below the Min-value, the output relay R switches into off-position. The output relay R switches into on-position again, if the voltage exceeds the Max-value.



### Window function (WIN)

When the supply voltage U is applied, the output relay R switches into on-position, if the measured voltage is within the adjusted window. When the measured voltage left the window between Min and Max, the output relay R switches into off-position. The output relay R switches into on-position again, if the voltage re-enter the adjusted window.



## **Connections**

1~

AC





1~

24V

AC



## **Dimensions**



# **Ordering information**

| Types                             | Rated voltage U <sub>N</sub> | Functions | Switching<br>threshold U <sub>s</sub>  | Delay | Hysteresis  | Part. No.   |       |
|-----------------------------------|------------------------------|-----------|--|-------|-------------|-------------|-------|
| E1IUM230V01                       | 24V AC/DC 230V               | U. W      | Max 80% to 120%<br>of U <sub>N</sub><br>Min 75% to 115%<br>of U <sub>N</sub> | -     | adjustable  | 1340101     |       |
| RELEASE 2009/0                    | 7                            |           |  |       | Le          | le          |       |
| Subject to alterations and errors |                              |           |  |       | Technik Bra | aucht Kontr | -olle |