

TECHNICAL DATA

Fluke i3000s AC Current Clamp



Key features

The i3000s is a clamp-on AC Current Clamp for use with oscilloscopes and multimeters with banana input using the supplied Dual Banana to BNC Adapter.

Product overview: Fluke i3000s AC Current Clamp

Very High AC Current Clamp

Fluke Current clamps are the ideal tools to extend the current ranges of Fluke tools.

The i3000s is a clamp-on AC Current Clamp for use with oscilloscopes and multimeters with banana input using the supplied Dual Banana to BNC Adapter. The clamp is optimized for measurement on power distribution systems.

Specifications: Fluke i3000s AC Current Clamp


Specifications	
Nominal current range	30 A 300A 3000A
Continuous current range	1 A - 30 A 1 A - 300 A 1 A - 3000 A



Maximum non-destructive current	4000 A	
Lowest measureable current	1 A	
Basic accuracy	2% + 2 A (48-65 Hz) % reading + floorspec	
Useable frequency	10 Hz - 100 kHz	
Output level(s)	10 mv/A 1 mv/A 0.1 mv/A	
Safety Specifications		
Safety	CAT III, 600 V	
Maximum voltage	600 V AC	
Mechanical and General Specifications		
Warranty	1 year	
Maximum conductor diameter	64 mm	
Output cable length	2.1 m	
BNC adapter	Yes	



Ordering information



Fluke-i3000s Fluke i3000s AC Current Clamp



Fluke. Keeping your world up and running. ${\it \$}$

Fluke Europe B.V.
P.O. Box 1186
5602 BD Eindhoven
The Netherlands
www.fluke.com/en
@2023 Fluke Corporation. All rights reserved.
Data subject to alteration without notice.
07/2023

For more information call: In Middle East/Africa +31 (0)40 267 5100

Modification of this document is not permitted without written permission from Fluke Corporation.